VZ-49, 55 & 65UHD

49", 55" & 65" UHD LED MONITOR USER MANUAL

4K UHD LED Monitor





Please read this manual thoroughly before use, and keep it handy for future reference.

CONTENTS

Sarety Instruction	3
1. Mark Indication & Substance	4
2. Warning & Caution	4
3. FCC RF INTERFERENCE STATEMENT	6
4. RoHS Compliance	7
Installation	8
1. Feature & Package	8
2. Stand Installation	9
3. Interface	10
Function	1:
1. Remote Function	1
2. Monitor Button Function	12
3. OSD Control and Function	13
4. Media Player	2:
RS232 Command	28
Mounting Guide	30
Specification	3:
Trouble Shooting	32
RMA	33
Warranty	36

SAFETY INSTRUCTION

Important Safety Instruction

- 1. Read all warnings.
- 2. Follow all instructions to ensure longevity of monitor.
- 3. Do not place the monitor near water.
- 4. Clean only with dry cloth.
- 5. Do not block any ventilation openings. Install in accordance with the manufacturer's instructions.
- Do not install near any heat sources such as radiators, heat registers, stoves, or other heat generating devices.
- 7. Do not override the safety purpose of the polarized or grounding-type plug.
- 8. A polarized plug has two blades with one wider than the other.
- 9. A grounding type plug has two blades and a third grounding prong.
- 10. The wide blade or the third prong is provided for your safety.
- 11. If the provided plug does not fit into your outlet, consult with electrician for replacement of the outlet.
- 12. Protect the power cord from being walked on or pinched particularly at plugs, convenience receptacles and the point where it connects to the monitor.
- 13. Only use attachment/accessories specified by the manufacturer.
- 14. Use only with the cart, stand, tripod, bracket or table specified by the manufacturer or sold with the monitor. When a cart is used, use caution when moving the cart & monitor in combination to avoid injuries.



- 15. Unplug the monitor during lightning storms or when unused for long periods of time.
- 16. Refer all servicing to qualified service personnel. Servicing is required when the monitor has been damaged in any way.

The monitor shall not be exposed to dripping or splashing and objects containing liquids such as vases shall not be placed near the monitor.

The monitor should have ample distance (e.g. 10cm) from the wall for sufficient ventilation.

SAFETY INSTRUCTION

Important Safety Instruction

Mark Indication and Substance







CAUTION: TO REDUCE THE RISK OF ELECTRICAL SHOCK,
DO NOT REMOVE COVER (OR BACK). NO USER
SERVICEABLE PARTS INSIDE. REFER SERVICING TO
OUALIFIED SERVICE PERSONNEL



This symbol is intended to alert the user to the presence of uninsulated & dangerous voltage within the monitor's enclosure that may be of sufficient magnitude to constitute a risk of electric shock to persons.



This symbol is intended to alert the user to the presence of important operating and maintenance (servicing) instructions in the literature accompanying the monitor.

Warning

- · Do not use damaged or loose cables and plug.
- Do not pull the plug out by the wire nor touch the plug with wet hands.
- Use only a properly grounded plug and receptacle.
- Do not connect too many extension cords or plugs to one outlet.
- · Do not excessively bend the plug and wire.
- Do not disconnect the power cord while it's still plugged into the monitor.
- Do not place any heavy objects on the power cord. Damage to the cord may cause shock or fire.
- · Never open the monitor. There are no user-serviceable parts inside and opening will void warranty.
- · Removing covers may expose you to dangerous shock hazards or other risks.
- Keep any heating devices away from the power cable and monitor.
- Do not place the monitor near water.
- Do not insert objects of any kind into the monitor's open slots, as they may touch dangerous voltage points.
- Please follow the laws and regulations of your municipality to dispose the monitor properly.
- Do not use the monitor in high temperature, humid, dusty or oily areas.
- Do not install the monitor where it will be exposed to continual vibration.
- Keep the plastic packaging out of children's reach.
- If any damage is detected upon first opening the box, contact agency from which you bought the monitor directly.
- If your monitor does not operate normally in particular, if there is any unusual sound or smell coming from the
 monitor unplug it immediately and contact an authorized dealer or the service center.

SAFETY INSTRUCTION

Important Safety Instruction

A Caution

- If the connector between the plug and the pin is dusty or dirty, clean it properly using a dry cloth.
- Make sure to unplug the power cord before cleaning the monitor.
- Make sure to leave a gap between monitor and wall.
- · Do not drop the monitor when moving it.
- · Place your monitor in a location with low humidity and minimal dust.
- Install the monitor base on a showcase or shelf so that the end of the base does not protrude from the showcase or shelf.
- Do not place the monitor on an unstable or small surface area.
- Do not install inside a vehicle.
- Disconnect the plug from the outlet during storms or lightning or if it has not been used for a long time.
- Do not try to move the monitor by pulling on the power cord.
- Do not cover the vents on the monitor.
- When moving the monitor, turn off and unplug the power cord. Make sure that all cables, including HDMI
 cable and cables connected to other devices, are disconnected before moving it.
- Place the monitor out of children's reach as they could damage it by hanging onto it.

Available Temperature & Humidity

Operating Temperature: 32°F ~ 104°F / 0°C ~ 40°C

Operating Humidity: 20 ~ 85% RH

Storage Temperature: 50°F ~ 140°F / 10°C ~ 60°C

Storage Humidity: 10 ~ 90% RH

Dot Defect (dead pixel) of TFT

ViewZ monitors are manufactured using high-end semiconductor technology with precision ratings of 99.9% and above. However, it may be the case that certain RGB and white pixels seem darker (or entirely unlit i.e. black).

Modern production methods cannot guarantee an absolute fault-free monitor. To this effect, no LED manufacturer can guarantee a defect free panel. A few isolated pixel or sub-pixel faults are considered tolerable and different policies exist that govern the amount of these tolerable values.

While most pixel faults occur in isolated regions, a cluster of dead pixels or sub-pixels can sometimes form for which a separate ruling applies. A cluster is defined as an area of 5x5 pixels. ViewZ's policy on pixel failure: either as an isolated fault or in the form of a cluster is outlined on the website: www.viewzusa.com

FCC RF INTERFERENCE STATEMENT

Note

This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment.

This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference in which case the user will be required to correct the interference at his own expense.

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio, TV technician for help.
- · Only shielded interface cable should be used.

Finally, any changes or modifications to the equipment by the user not expressly approved by the grantee or manufacturer could void the users authority to operate such equipment.

▶ DOC COMPLIANCE NOTICE

This digital apparatus does not exceed the Class A limits for radio noise emissions from digital apparatus set out in the radio interference regulation of Canadian Department of communications.

Statement

- VGA and XGA are the registered trademark of IBM.
- VESA is the trademark of Video Electronics Standard Association.
- HDMI, HDMI logo and High-Definition Multimedia Interface (high definition multimedia digital interface) are the trademark or registered trademark of HDMI Licensing LLC.



If some company or product trademark is not particularly stated, the use of trademark has been fully recognized. Do not alter, decompile, disassemble, decode or conduct reverse engineering to the software installed in the product, or it can be deemed as breach of the law.

ROHS COMPLIANCE

Note

Name and contents of toxic and hazardous substances or elements contained in the product.

COMPONENT		FUNCTION			VALUE	
COMPONENT	(Pb)	(Hg)	(Cd)	(Cr ⁶⁺)	(PBB)	(PBDE)
LCD Screen	Х	0	0	0	0	0
Housing (Case)	0	0	0	0	0	
PCB assembly ¹⁾	X	0	0	0	0	0
Power cord & cable	X	0	0	0	0	0
Metal parts	0	0	0	0	0	0
Packing materials ²⁾	0	0	0	0	0	0
Remote controller	Х	0	0	0	0	0
Speaker	X	0	0	0	0	0
Accessories ³⁾	0		0		0	0

- 1) PCB assembly includes the PCB and the electronic components composed by the PCB
- 2) Packing materials include the carton, expandable polystyrene and etc.
- 3) Accessories include User Manual and etc.
- : The toxic and hazardous substance contain the homogeneous materials which components do not exceed the required limit, prescribed in the GB/T26572-2011 standards.
- X: The toxic and hazardous substance contain one or more homogeneous materials which component exceeds the required limit, prescribed in the GB/T26572-2011 standards.

Based on the provided information, the product contains hazardous material. Due to the limitation of the existing technology, the hazardous material cannot be replaced, although we have been striving to improve this situation. The product has the Environmental Friendly Use Period (EFUP) of 10 years.

The EFUP is valid only when the user operates in normal conditions as specified in the user manual.

Indicative description of Regulations on Regulation on Recycling and Disposal of Waste Electrical and Electronic Products..

When you will not use this product anymore or warranty is expired, please dispose / send this product to the qualified recycling station near your area. It is ordered / regulated by the Regulation on Recycling and Disposal of Waste Electrical and Electronic Products.

INSTALLATION

Installation Tools

The following tools may be required depending on your installation.















Assembly Components - provided

Your ViewZ monitor is shipped with all proper installation hardware and components. If there are parts missing and/or damaged, please stop the installation and contact ViewZ USA at (888)-998-4399.



TFT-LED Monitor (Qty 1)



Monitor Stand 1 set (Oty 2) M8 x L15 screws (Qty 6) M4 x L10 Screws (Qty 6)



110V Power Cable (Qty 1)



DP Cable (Qty 1)



User Manual (Qty 1) Remote Controller (Qty 1)

Mounting Option

VZ-43, 55 & 65UHD is VESA compliant and compatible with ViewZ monitor mounts. For more information, please contact ViewZ USA at (888)-998-4399.

Compatible ViewZ Wall Mount

- Part # WM71
- Tilting -10° ~ 0°
- Universal Mount · Load Capacity
 - 165 lbs /75 kg
- Part #
- Tilting Hor. ±3°



- Ver. 2° ~ +4°
- Universal Mount
- · Load Capacity 154 lbs /70 kg


Compatible ViewZ Ceiling & Free Standing Mount

- Part #
- CMKiT-04 Tilting -12° ~ +5°
- Part #

- Rotation 360°
- Universal Mount
- Load Capacity 110 lbs / 50 kg
- VZ-FSM2x2 Tilting ±4°
 - · Universal Mount
 - · Load Capacity
 - 110 lbs / 50 kg

STAND INSTALLATION

Stand Installation



- 1. Slot each stand into bottom holes of VZ-49UHD, VZ-55UHD & VZ-65UHD monitors.
- 2. Align the holes between stand and VZ-49UHD, VZ-55UHD & VZ-65UHD monitors
 - tighten provided screws (M8 x L15mm) into the holes.
- Attention! VZ-49UHD, VZ-55UHD & VZ-65UHD: User must use 6 * M8 x L15 mm screws (each side use 3 pieces) to assemble this monitor and the stand.
- WARNING! If the user uses longer screws than M8 x L15 mm, it may damage the unit.


Mounting Safety!

At least two people are recommended to install the mount.

VievCONNECTING WITH EXTERNAL EQUIPMENT

Interface Input Ports

The following image is the description of interface input ports of VZ-49, 55 & 65UHD



- 1. Power ON / OFF SWITCH
- 2. AC 100 ~ 240 V
- 3. HDMI 2 IN (Ver 1.4)
- 4. HDMI 1 IN (Ver 2.0)
- 5. DP 2 IN x 1
- 6. DP 1 IN x 1

- 7. AUDIO OUT
- 8. RS-232 IN
- 9. RS-232 OUT
- 10. DP OUT
- 11. USB (OPS Only) IN
- 12. Media Player USB IN
- 13. Media Player SD Card IN


Interface Resolution & Refresh Rate

Interface Input Source	Max Resolution	Refresh Rate
HDMI (Ver. 2.0)	3840 x 2160	60Hz
HDMI (Ver. 1.4)	3840 x 2160	30Hz
DP (Ver. 1.2)	3840 x 2160	60Hz

REMOTE FUNCTION

Remote Controller


- 1. POWER Power On & Off
- 2. MENU Enter the monitor OSD menu
- 3. SOURCE Change the input source
- ARROW Monitor OSD control left, right, select or enter, volume up & volume down
- 5. UP, DOWN Not support
- 6. ROTATE Rotate the display
- 7. BACK Exit or return to the previous menu
- 8. OPS Enter the OPS mode
- 9. PIP Set PIP mode
- 10. MUTE Mute audio
- 11. MEDIA (Media Player) Enter the media play mode
- 12. HOME Enter the root menu of media play
- 13. SETTINGS Enter the setup window of media play
- 14. ARROW Media Player control left, right, up, down & select / enter
- 15. MENU Enter the monitor OSD menu
- 16. BACK Exit or return to the previous menu
- VOLUME DOWN, DELETE (BACKSPACE), VOLUME UP -Control the audio of media play



Display image, sound and custom settings can be adjusted in OSD (On Screen Display) menu by remote controller. To adjust monitor setting value:

- 1. Press the MENU button to enter the OSD menu
- 2. Press the **SOURCE** button to select input source
- 3. Press the SELECT buttons to select the desired sub MENU. The selected sub MENU will be highlighted
- 4. Press the ◀ / ▶ button to enter the sub MENU for adjusting items
- 5. Change the value as user want to adjust by using the ◀ / ▶ buttons
- 6. Press the SELECT button to confirm
- 7. Press the BACK button to exit & save adjustment value on sub MENU
- 8. Press the MUTE button to mute audio audio only works with a selected input source

On Monitor, Button Control



- Source Select an input source
- Menu Enter or exit the OSD / Select a menu on OSD
- Left & Right

 (VOL)

 Select the submenu / Adjust the value of feature

 (hot key) set the volume up / down
- 4. PIP & PBP Select the display type
- 5. Rotate
 Rotate the screen
- Power Monitor power on / off

Monitor Button Function

All picture, sound settings and setup can be adjusted in OSD (On Screen Display) menu. To adjust the OSD screen:

- 1. Press the MENU button to enter the OSD MENU
- Press the SOURCE button, then press the ◀ I ▶ buttons to select input source
 Press the MENU button to select a desired input source
- Press the ◀ / ▶ buttons to select the desired main MENU. The selected main MENU is highlighted
- 4. Press the MENU buttons to select the desired sub MENU. The selected sub MENU is highlighted
- 5. Change the value you wish to adjust by using the ◀ / ▶ buttons
- 6. Press the MENU button to confirm the adjustment on sub MENU
- 7. Press the MENU button to exit the sub MENU and go back to the main MENU
- 8. Press the MENU button to exit the OSD MENU

Select Input Source



Press 'SOURCE' button on monitor or press the button on remote controller.

Press ◀ / ▶ button to change input source and then press 'MENU' button to select input source on monitor.

Press ◀ / ▶ button to change input source and then press • button to select input source on remote controller.


Detect Source Signal Message

If user connects any input source, ViewZ UHD series monitor will display current input source resolution and frequency.

Volume



Press 'Mute' button on remote controller to mute the sound.




Press the 4/ buttons (on monitor) to adjust volume on the monitor.

Press the or buttons (on remote controller) to adjust volume on the monitor.

PICTURE







	FUNCTION	VALUE
PICTURE MODE	Adjust the image color setting	
BACKLIGHT	Adjust the monitor backlight level	0 ~ 100 (default: 50)
BRIGHTNESS	Provide enhanced contrast and sharpness	0 ~ 100 (default: 50)
CONTRAST	Adjust the contrast level	0 ~ 100 (default: 50)
SHARPNESS	Adjust the sharpness level	0 ~ 4 (default: 2)
CLONE	Turn on / off clone mode	

COLOR







	FUNCTION	VALUE
COLOR	Adjust the color setting	
GAMMA	Adjust the brightness of monitor	Off/1.8/2.0/2.2/2.4 (default:off)
TEMPERATURE	Adjust the color setting	5800/6500/7500/9300/sRGB/
		User(default: R/G/B 128,
		R:0~256, G:0~256, B:0~256)
COLOR EFFECT	Adjust the color effect	Standard / Game / Movie
		Photo / Vivid /
		User (R/Y/B/C/G/M,
		Hue: 0 ~ 100, SAT: 0 ~ 100)
HUE	Adjust the hue level	0 ~ 100 (default: 50)
SATURATION	Adjust the saturation level	0 ~ 100 (default: 50)
PCM	Adjust the PCM level	sRGB / Adobe RGB / User / Native

ADVANCE & INPUT







	FUNCTION	VALUE
ADVANCE	Adjust the video setting	
ASPECT RATIO	Adjust the video format	Full/16:9/4:3/5:4/ 1:1 /User
DCR	Turn on / off overdrive	ON / OFF (default: OFF)



	FUNCTION	VALUE
INPUT 1)	Select the input source	DP1 / DP2 / OPS / MEDIA
		HDMI 1 / HDMI 2

1) User can select the input source for PIP, PBP, 4P & Full sceen

AUDIO





	FUNCTION	VALUE
AUDIO	Set the volume setup	
VOLUME	Adjust the volume level	0 ~ 100 (default: 50)
MUTE	Turn on / off the sound	OFF / ON (default: OFF)
AUDIO SOURCE 1)	Select the audio output source	Analog / DP1 / DP2 / OPS /
		MEDIA / HDMI 1 / HDMI 2

¹⁾ Available on the mode of 2P LR, 2P TB, 2P PIP & 4P

OTHER








	FUNCTION	VALUE
OTHER	Adjust OSD preferences	
RESET	Reset the monitor settings to the factory default	YES / NO
MENU TIME	Adjust the OSD display time	0 ~ 60 (default: 10) sec
OSD H POSITION	Adjust the horizontal position of OSD	0 ~ 100 (default: 50)
OSD V POSITION	Adjust the vertical position of OSD	0 ~ 100 (default: 50)
LANGUAGE	Set the language of the OSD menu	English / French / Portuguese
		Japanese / Spanish
		(default: English)
TRANSPARENCY	Set the OSD transparency	0 ~ 200 (default: 0)
LED	Apply user selected values	Red (ON/OFF), Green (ON/OFF),
		Blue (ON/OFF)
ROTATE	Rotate the OSD	0° / 90° / 180° / 270°

DISPLAY MODE





◀ / ► MOVE / ADJUST
 RETURN


	FUNCTION	VALUE
DISPLAY MODE	Select the display type	
1P	Set a screen by an input source	DP1 / DP2 / OPS / MEDIA
		HDMI 1 / HDMI 2
2P LR	Set the PBP screen as the left and right display	DP1 / DP2 / OPS / MEDIA
		HDMI 1 / HDMI 2
2P TB	Set the PBP screen as the top and bottom display	DP1 / DP2 / OPS / MEDIA
		HDMI 1 / HDMI 2
2P PIP	Set the PIP screen	DP1 / DP2 / OPS / MEDIA
		HDMI 1 / HDMI 2
4P	Set the quad view	DP1 / DP2 / OPS / MEDIA
		HDMI 1 / HDMI 2

Attention!

To select the input source for **2P LR**, **2P TB**, **2P PIP** & **4P**, user should click the button (on remote controller) or select the mode at OSD. After selecting a mode, user can select the input source for each region at OSD / Input (refer to page 17).

If no source is assigned to each section, the monitor will show 'No Signal' sign.

Media Card Interface



Connect USB or SD card

 Connect USB or SD card devices to USB or SD Card slot located at the back of the UHD

Remove USB or SD card

- 1. Return to the main menu and press exit
- 2. Remove the USB & SD card from the slot

Media Player OSD



	FUNCTION
MOVIE	Plays video files from the USB or internal storage
PICTURE	Displays image files from the USB or internal storage
MUSIC	Plays music files from the USB or internal storage
FOLDER	Copy, save, rename and search the file and folder
SETTINGS	Change the setup of media player

Movie





When user select MOVIE on the entry menu of Media Play:

- 1. Press the button (on remote controller) and then press

 ✓ / ► / ▲ / ▼ (ARROW) buttons to select a movie file to display.
- Press the button (on remote controller) to select movie files to play and then press button to play the movie.
 *Note: If you have more than one movie file, selected movie files will display one by one. If there are movie files in a folder and select a movie file to play, other movie files will be played after the selected movie file playing.
- 3. Press the Dutton (on remote controller) or button (on the OSD) to pause the movie play.
- 4. Press the THE PREVIOUS & NEXT buttons (on the OSD) to play next or previous movie.
- 5. Press the CHOOSE_TIME button (on the OSD) to jump to the specific time to play.
- 6. Press the button (on remote controller) to go back to the previous menu.
- 7. Press the button or button (on remote controller) to volume up & down.
- 8. Press the button (on remote controller) to adjust video display setting. Use can adjust;

Screen Size (Format): select Full screen, Original scale, Proportional play, 16:9 Equal Width, 16:9 Contour, 4:3 Equal Width, 4:3 Contour

Play Mode: select Play in Sequence, Loop All, Single Cycle, Random Play, Single Play

Track settings: show video codec information

Subtitle: select the applicable subtitle

Subtitle Encoding: select the applicable subtitle encoding among UTF-8, UTF0-16LE, ISO8859-1, EUC-JP, EUC-KR, GBK, BIG5

- 9. Press the button (on remote controller) to go back to the home screen of media play.
- 10. Press the button (on remote controller) to open the Media OSD MENU.
- 11. Press the button (on remote controller) to turn off/on the Media Play.

Picture





When user select PHOTO on the entry menu of Media Play:

- Press the button to select image files to play and then press ► (PLAY) button to display the image or slide-show.
 *Note: If you have more than one image file, selected image files will display one by one. If there are image files in a folder and select a image file to play, other image files will be played after the selected image file playing.
- 3. Press the 🔁 button (on remote controller) or 🕕 🖒 button (on the OSD) to pause & play the music play.
- Press the ◀ / ► buttons (on remote controller) to display next or previous image.
- 5. Press the button (on remote controller) to go back to the previous menu.
- 6. Press the button or button (on remote controller) to volume up & down.
- Press the button (on remote controller) to adjust image display setting. Use can adjust;
 Switching Mode: select the image switching mode Default, Alpha, Rotate, Flip, Accordion, ZoomFade, Fade, ZoomCenter, ZoomStack, Stack, Depth, Zoom, Mosaic

Picture Preview Time: select the image display time (second) - 0s, 1s, 3s, 7s, 10s, 30s, 1min, 3min Background Music: turn on/off the background music

Picture Ratio: select the display ratio - Full-Screen Display, Proportional Display, Proportional Zoom

- 8. Press the button (on remote controller) to go back to the home screen of media play.
- 9. Press the button (on remote controller) to open the Media OSD MENU.
- 10. Press the button (on remote controller) to turn off/on the Media Play.

Music





When user select MUSIC on the entry menu of Media Play:

- 1. Press the button (on remote controller) and then press

 ✓ / ► / ▲ / ▼ (ARROW) buttons to select a music file to display.
- 2. Press the

 button to select music files to play and then press ► (PLAY) button to play the music.
- *Note: If you have more than one music file, selected movie files will display one by one. If there are music files in a folder and select a music file to play, other music files will be played after the selected music file playing.
- 3. Press the 📵 button (on remote controller) or 🕕 🕟 button (on the OSD) to pause & play the music play.
- Press the ◀ & ▶ buttons (on the OSD) to play next or previous movie.
- 5. Press the button (on the OSD) to loop the current playing music file.
- 6. Press the button (on remote controller) to go back to the previous menu.
- 7. Press the button or button (on remote controller) to volume up & down.
- 8. Press the button (on remote controller) to switch between play control and music file list.
- 9. Press the button (on remote controller) to go back to the home screen of media play.
- 10. Press the button (on remote controller) to open the Media OSD MENU.
- 11. Press the button (on remote controller) to turn off/on the Media Play.

Folder



When user select FOLDER on the entry menu of Media Play:

- 1. Press the
 button and then press
 / ▶ / / ▼ (ARROW) buttons to select a file or folder to display.
- 2. Press the delutton to select a file or folder to see or play the inside folder or the file.

*Note: If you select a file, a selected file (movie, music or picture) can be played.





3. Select a file or folder, press the button to copy, delete, rename and paste a file or folder.

Settings





When you select **SETTINGS** on the entry menu of **Media Play**:


User can adjust the Media Play settings. Press the

button (on remote controller) and then press

/ ► / ▲ / ▼ (ARROW) buttons to adjust the value.

	FUNCTION	VALUE
LANGUAGE	Set the language of the Media Play	English / French / Spanish /
		Japanese / Portugese / Korean /
		Italian / Chinese / Deutsch /
		Russian / Islam
DISPLAY RESOLUTION	Select the resolution of input source	AUTO / 4K / 1080p / 720p
SCREEN ZOOM	Adjust the zooming level	
AUDIO SETTINGS	Select the sound source	Default / SPDIF Source Code /
		HDMI Source Code
SCREEN ROTATION	Rotate the screen	0° / 90° / 180° / 270°
AUTOPLAY	Set the autoplay of Media Play contents	OFF / MOVIE / MUSIC / PICTURE /
		Movie&Picture / Picture&Music
		(default: OFF)

Settings



	FUNCTION	VALUE
CYCLIC MODE	Select the playing style of contents	Play in Sequence / Loop All /
		Single Cycle / Random Play /
		Single Play
VIDEO DISPLAY RATIO	Adjust the video format at Movie Display	Full Screen / Original Scale /
		Proportional Play /
		16:9Equal Width / 16:9Contour/
		4:3Equal Width / 4:3Contour
VIDEO MEMORY	Use the video memory at Movie Display	ON / OFF (default: OFF)
PICTURE PREVIEW MODE	Set the switching mode of images at Picture Display	Default / Alpha / Rotate / Cube /
		Flip / Accordion / ZoomFade /
		Fade / ZoomCenter / ZoomStack /
		Stack / Depth / Zoom / Mosaic
PICTURE PREVIEW TIME	Set the preview time of images at Picture Display	1s / 3s / 5s / 7s / 10s / 30s /
		1min / 3min
COPY TO INTERNAL	Copy & save the file/folder from external to internal storage.	ON / OFF
STORAGE	VZ-UHD series monitor has 5GB of internal memory space.	
RESTORE DEFAULT SETTINGS	Reset the media play settings to the factory default	YES / NO
VERSION	Check the media play version	


RS232 COMMAND

RS 232 Communication Command & Relevant Configurations

In consideration of secondary development of centralized control circumstances, the function of RS232 communication command & relevant configuration setup are described as follow:

RS 232 communication settings

Baud rate: 9600 bps
Parity check bit: none
Data bit: 8 bits
Stop bit: 1 bits



RS 232 input

RS 232 output

- RS 232 input
 - #1 RX
 - #3 Ground
- RS 232 output
 - #3 Ground
 - #8 TX

RS232 COMMAND

RS 232 Communication Command & Relevant Configurations

In consideration of secondary development of centralized control circumstances, the POWER ON/OFF function of RS232 communication command & relevant configuration setup are described as follow:

RS 232 communication settings

Baud rate : 9600 bps Data bit : 8 bits
Parity check bit : none Stop bit : 1 bits

RS232 communication command

PARAMETER (DATA) DESCRIPTION		SET COMMAND
POWER OFF	RS232 command:	53 47 01 00 00 9B
POWER ON	RS232 command:	53 47 01 00 01 9C
MUTE OFF	RS232 command:	53 47 01 01 00 9C
MUTE ON	RS232 command:	53 47 01 01 01 9E
DP1	RS232 command:	53 47 01 03 00 9E
DP2	RS232 command:	53 47 01 03 01 9F
OPS	RS232 command:	53 47 01 03 02 A0
HDMI1	RS232 command:	53 47 01 03 03 A1
HDMI2	RS232 command:	53 47 01 03 04 A2
Media	RS232 command:	53 47 01 03 05 A3


CET CO. 41 4 4 1 1 D

The above commands are hexadecimal.

MOUNTING GUIDE

Wall Mounting (Optional)

VZ-49,55&65UHD monitors are suitable for universal wall mounting (not included).



VZ-49UHD: Universal Wall Mount (VESA) 400mm x 400mm
 VZ-55UHD: Universal Wall Mount (VESA) 400mm x 400mm
 VZ-65UHD: Universal Wall Mount (VESA) 400mm x 400mm

WARNING!

If user uses screws longer than M6 x L14 mm for VZ-49UHD, VZ-55UHD, VZ-65UHD it may cause damage to the unit. Please use the screws of correct and size and length as instructed.

\wedge

Mounting Safety!

At least two people are recommended to safely install the mount and monitor.

SPECIFICATION

ı	Model No.	VZ-49UHD	VZ-55UHD	VZ-65UHD
	Size & Type	49"	55"	65"
	Panel Type	49" 4K LED Backlit Monitor	55" 4K LED Backlit Monitor	65" 4K LED Backlit Monitor
	Pixel Pitch	0.27963 (H) x 0.27963 (V) mm	0.315 (H) x 0.315 (V) mm	0.372 (H) x 0.372 (V) mm
	Brightness	350 cd/m² (Typical)	350 cd/m² (Typical)	350 cd/m² (Typical)
	Contrast Ratio	1200 : 1 (Typ.)	1300 : 1 (Typ.)	1200 : 1 (Typ.)
	Viewing Angle		178° / 178°	
LCD	Display Color	1.07 Billion Colors (10 Bit)		
	Response Time	< 9 ms	< 9 ms	< 8 ms
	Active Display Area	1075.2 (H) x 607.2 (V) mm	1211.1 (H) x 681.9 (V) mm	1428.5 (H) x 803.5 (V) mm
	Resolution	3840 (H) x 2160 (V) @ 60Hz		
	Refresh Rate (Max.)	HDMI 2.0 - 3840x2160 @60Hz HDMI 1.4 - 3840x2160 @30Hz DP 1.2 - 3840x2160 @60Hz		
	Aspect Ratio	16:9 (1.78:1)		
Case Type Color Temperature			Black Metal	
		5800 / 6500 / 7500 / 9300 / sRGB / USER		
	Speaker	2 x 5W	2 x 5W	2 x 5W
Operating Temperature		32°F ~ 104°F / 0°C ~ 40°C		
Operating Humidity			20 ~ 85% RH	
		Net : 36.15 lbs / 16.4 kg	Net : 47.39 lbs / 21.5 kg	Net : 73.85 lbs / 33.5 kg
Weight	weight	Gross: 52.91 lbs / 24.0 kg	Gross: 66.13 lbs / 30.0 kg	Gross: 95.01 lbs / 43.1 kg
INTERFACE		HDMI 1.4 ln x 1, HDMI 2.0	0 In x 1, DP IN x 2, DP OUT x 1, RJ45	5 (RS-232) In / Out x 1 / 1,
Audio Out x 1, USB (Media Player) In x 1, SD Card (Media Player) In x 1		edia Player) In x 1		
INTER	FACE (OPS - Option)	USB (Typc C) In x 1, USB 2.0 (Type A) In x 2, USB 3.0 (Type A) In x 2,		
		RJ45 In x 1, HDMI Out x 1, Mic. In x 1, Audio Out x 1		
Safety	y & EMC Certification CE / FCC / KC / RoHS			
Electrical Ratings			AC 100-240V, 50/60Hz	
Pov	ver Consumption	≤ 160 W	≤ 170 W	≤ 240 W
	Accessories	AC 110V Power Cabl	e x1, User's Manual x1, Remote Co	ntroller x1, Stand x1

TROUBLESHOOTING GUIDE

- Check the following before calling for service.
- If the same problems continue after checking, contact the reseller you purchased the monitor from.

At start	We recommend that you test with different input sources when you have trouble with the current input source. If symptom persists, follow the instructions below. After following the instructions below, please contact us at 1-888-99-VIEWZ.
No image or Noise on the screen	 Make sure the cable is correctly plugged into the outlet. Make sure the power cable is correctly plugged into the monitor. Make sure the cable is correctly connected between monitor & source. Check brightness and see if brightness is set to 'Ø'. Check video source.
Incorrect display or Half display	- Check your video source. - Reset video source : connection, cable replacement, setting & more.
Flickering and shadow image	- Check your input source setting for resolution and phase (Hz).
The audio function is not working	- Check the volume and make sure MUTE is not on Check HDMI / DP / Audio port cable connection.
LED is flickering or no image	- Check the interface cable connection and make sure it's plugged in correctly Check the input source.

TERMS OF WARRANTY / RMA

- The warranty period for this monitor is 3 years. The warranty will be voided for the scenarios listed below.
- You can also download the manual and information of VIEWZ web site: VIEWZUSA.COM

Cases of Non-Warranty Coverage	When power feed to the monitor exceeds capacity and causes damage.	
	Accident, Abuse, Misuse, Neglect, Fire, Water/liquids, Lightning or any act of nature.	
	Damaged by dropping, throwing and hitting the monitor.	
	Failure caused by users attempt to modify the product.	
	Failure by limited life of parts such as LED Lamps and any other consumables.	
	Damaged by using third party power cable, unstable power input and electric shock.	

- * Above information can be changed without notification please check our website or contact ViewZ representative for latest RMA service policy.
- * When shipping the monitor for RMA, make sure to pack safely to ensure the monitor is not damaged during shipping.

NOTE

NOTE

_
_

WARRANTY

ViewZ USA LIMITED 3 YEAR WARRANTY

What and Who is Covered by this Limited Warranty and for How Long

ViewZ USA warrants this product to be free from defects in material and workmanship for 3 years to the original owner of this product. The limited warranty is valid only for the original purchaser of the product.

What ViewZ USA Will Do

At their sole discretion, ViewZ USA will repair or replace any product or product part that is defective. If ViewZ USA chooses to replace a defective product or part, a replacement product or part will be shipped to you at no charge, but you must pay any labor costs.

What is Not Covered; Limitations

ViewZ USA disclaims any liability for damage to mounts, adapters, displays, projectors, other property, or personal injury resulting, in whole or in part, from improper installation, modification, use or misuse of its products.

ViewZ USA disclaims all other warranties, express or implied, including warranties of merchantability and fitness for a particular purpose. ViewZ USA is not responsible for incidental or consequential damages, including but not limited to, inability to use its products or labor costs for removing and replacing defective products or parts. Some states do not allow the exclusion or limitation of incidental or consequential damage, so the above limitation or exclusion many not apply to you.

What Customers Must Do for Limited Warranty Service

If you discover a problem that you think may be covered by the warranty you MUST REPORT it in writing to the address below within thirty (30) days. Proof of purchase (an original sales receipt) from the original consumer purchaser must accompany all warranty claims. Warranty claims must also include a description of the problem, the purchaser's name, address, and telephone number. General inquiries can be addressed to ViewZ USA Customer Service at 1-888-998-4399. Warranty claims will not be accepted over the phone or by fax.

ViewZ USA Attn: Warranty Claim 177 W. Orangethorpe Ave. Placentia. CA 92870

How State Law Applies

This warranty gives you specific legal rights, and you may also have other rights which vary from state to state.

Disclaimer

ViewZ USA intends to make this manual accurate and complete. However, ViewZ USA makes no claim that the information contained herein covers all details, conditions or variations, nor does it provide for every possible contingency in connection with the installation or use of this monitor. The information contained in this document is subject to change without notice or obligation of any kind. ViewZ USA makes no representation of warranty, expressed or implied, regarding the information contained herein. ViewZ USA assumes no responsibility for accuracy, completeness or sufficiency of the information contained in this document.

Contact Us

© ViewZ USA

NORTH AMERICA

177 W. Orangethorpe Ave. Placentia, CA 92870 USA and Canada Phone: 1-888-998-4399 Fax: 1-714-996-1138 Other Locations

Phone: (001) 888-998-4399 Fax: (001) 714-996-1138