# VZ-CME SERIES 19.5", 21.5" and 24" ECONOMIC

LED CCTV MONITOR USER MANUAL





Please read this manual thoroughly before use, and keep it handy for future reference.



# CONTENTS

Safety Instruction	3
1. Mark Indication & Substance	4
2. Warning	4
3. Caution	5
4. Operational Temperature & Humidity	5
5. Dot Defect (dead pixel) of TFT	5
6. FCC RF INTERFERENCE STATEMENT	6
Installation	7
1. Package	7
2. Interface	8
3. Remote Control Function	9
Function	10
1. Monitor Button Function	10
2. OSD Control and Function	11
Mounting Guide	16
Specification	17
Trouble Shooting	18
RMA	19
Warranty	20

# **SAFETY INSTRUCTION**

### **Important Safety Instruction**

- 1. Read all warnings.
- 2. Follow all instructions to ensure longevity of monitor.
- 3. Do not place the monitor near water.
- 4. Clean only with dry cloth.
- 5. Do not block any ventilation openings. Install in accordance with the manufacturer's instructions.
- 6. Do not install near any heat sources such as radiators, heat registers, stoves, or other heat generating devices.
- 7. Do not override the safety purpose of the polarized or grounding-type plug.
- 8. A polarized plug has two blades with one wider than the other.
- 9. A grounding type plug has two blades and a third grounding prong.
- 10. The wide blade or the third prong are provided for your safety.
- 11. If the provided plug does not fit into your outlet, consult with electrician for replacement of the outlet.
- 12. Protect the power cord from being walked on or pinched particularly at plugs, convenience receptacles and the point where it connects to the monitor.
- 13. Only use attachment/accessories specified by the manufacturer.
- 14. Use only with the cart, stand, tripod, bracket or table specified by the manufacturer or sold with the monitor. When a cart is used, use caution when moving the cart & monitor in combination to avoid injuries.
- 15. Unplug the monitor during lightning storms or when unused for long periods of time.
- 16. Refer all servicing to qualified service personnel. Servicing is required when the monitor has been damaged in any way

The monitor shall not be exposed to dripping or splashing and objects containing liquids, such as vases shall be placed near the monitor.

The monitor should have ample distance (e.g. 10cm) from the wall for sufficient ventilation.



# **SAFETY INSTRUCTION**

## **Important Safety Instruction**

## Mark Indication and Substance



CAUTION : TO REDUCE THE RISK OF ELECTRICAL SHOCK, DO NOT REMOVE COVER (OR BACK). NO USER SERVICEABLE PARTS INSIDE. REFER SERVICING TO QUALIFIED SERVICE PERSONNEL



This symbol is intended to alert the user to the presence of uninsulated & dangerous voltage within the monitor's enclosure that may be of sufficient magnitude to constitute a risk of electric shock to persons.

This symbol is intended to alert the user to the presence of important operating and maintenance (servicing) instructions in the literature accompanying the monitor.

## **Warning**

- Do not use damaged or loose cables and plug.
- Do not pull the plug out by the wire nor touch the plug with wet hands.
- Use only a properly grounded plug and receptacle.
- Do not connect too many extension cords or plugs to one outlet.
- Do not excessively bend the plug and wire.
- Do not disconnect the power cord while it's still plugged into the monitor.
- Do not place any heavy objects on the power cord. Damage to the cord may cause shock or fire.
- Never open the monitor. There are no user-serviceable parts inside and opening will void warranty.
- Removing covers may expose you to dangerous shock hazards or other risks.
- Keep any heating devices away from the power cable and monitor.
- Do not place the monitor near water.
- Do not insert objects of any kind into the monitor's open slots, as they may touch dangerous voltage points.
- Please follow the laws and regulations of your municipality to dispose of the tube properly.
- Do not use the monitor in high temperature, humid, dusty or oily areas.
- Do not install the monitor where it will be exposed to continual vibration.
- Keep the plastic packaging out of children's reach.
- If any damage is defected upon first opening the box, contact agency from which you bought the monitor directly.
- If your monitor does not operate normally in particular, if there is any unusual sound or smell coming from the monitor unplug it immediately and contact an authorized dealer or the service center.

# **SAFETY INSTRUCTION**

### **Important Safety Instruction**

# **C**aution

- If the connector between the plug and the pin is dusty or dirty, clean it properly using a dry cloth.
- Make sure to unplug the power cord before cleaning the monitor.
- Make sure to leave a gap between monitor and wall.
- Do not drop the monitor when moving it.
- Place your monitor in a location with low humidity and a minimum dust.
- Install the monitor base on a showcase or shelf so that the end of the base does not protrude from the showcase or shelf.
- Do not place the monitor on an unstable or small surface area.
- Do not install inside a vehicle.
- Disconnect the plug from the outlet during storms or lightning or if it has not been used for a long time.
- Do not try to move the monitor by pulling on the power cord.
- Do not cover the vents on the monitor.
- When moving the monitor, turn off and unplug the power cord. Make sure that all cables, including HDMI cable and cables connected to other devices, are disconnected before moving it.
- Place the monitor out of children's reach, as they could damage it by hanging onto it.

### \land Available Temperature & Humidity

- Operating Temperature :  $14^{\circ}F \sim 122^{\circ}F / -10^{\circ}C \sim 50^{\circ}C$
- Operating Humidity : 20 ~ 70% RH

### Dot Defect (dead pixel) of TFT

ViewZ monitors are manufactured using high-end semiconductor technology with precision ratings of 99.9% and above. However, it may be the case that certain RGB and white pixels seem darker (or entirely unlit i.e. black).

Modern production methods cannot guarantee an absolute fault-free monitor. To this effect, no LED manufacturer can guarantee a defect free panel. A few isolated pixel or sub-pixel faults are considered tolerable and different policies exist that govern the amount of these tolerable values.

While most pixel faults occur in isolated regions, a cluster of dead pixels or sub-pixels can sometimes form for which a separate ruling applies. A cluster is defined as an area of 5x5 pixels. ViewZ's policy on pixel failure: either as an isolated fault or in the form of a cluster is outlined on the website: www.viewzusa.com

# FCC RF INTERFERENCE STATEMENT

### Note

This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment.

This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference in which case the user will be required to correct the interference at his own expense.

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio, TV technician for help.
- Only shielded interface cable should be used.

Finally, any changes or modifications to the equipment by the user not expressly approved by the grantee or manufacturer could void the users authority to operate such equipment.


### ► DOC COMPLIANCE NOTICE

This digital apparatus does not exceed the Class A limits for radio noise emissions from digital apparatus set out in the radio interference regulation of Canadian Department of communications.

# INSTALLATION

## **Installation Tools**

The following tools may be required depending on your installation.



## Assembly Components - provided

Your ViewZ monitor is shipped with all proper installation hardware and components. If there are parts missing and/or damaged, please stop the installation and contact ViewZ USA at (888)-998-4399.



## **Mounting Option**

Your ViewZ monitor is compatible with ViewZ monitor mounts. For more information, please contact ViewZ USA at (888)-998-4399.


#### Wall Mount



# **CONNECT EXTERNAL EQUIPMENTS**

# Interface Input Ports

The following image is the description of interface input ports of BNC Monitor




- 1. Audio IN / OUT
- 2. VGA IN
- 3. HDMI IN
- 4. DVI IN
- 5. DC 12V IN

# **REMOTE FUNCTION**

### **Remote Controller Function**

- 1. Power
- 2. Auto: Auto Adjustment for Input Source
- 3. Up
- 4. Right
- 5. Menu: Enter OSD Menu
- 6. Left
- 7. Down
- 8. Mute: Sound Mute On/Off
- 9. Exit: OSD Selection Cancel & Back / Close OSD Menu
- 10. 4:3/16:9: Adjust Aspect Ratio
- 11. HDMI Input Select
- 12. DVI Input Select
- 13. VGA Input Select




Display image, sound and custom settings can be adjusted in OSD (On Screen Display) menu by remote controller. To adjust monitor setting value :

- 1. Press the 'MENU' button to enter the OSD menu
- 2. Press the ▲ / ▼ buttons to select the desired sub-menu. The selected sub-menu will be highlighted
- 3. Press the 'MENU' button to enter the sub-menu to adjust different items
- 4. 4. Change the value you wish to adjust by using the ◀ / ► buttons
- 5. Press the 'MENU' button to confirm the adjustment on sub-menu
- 6. Press the 'EXIT' button to exit the sub-menu to go back to the previous menu
- 7. Press the 'AUTO' button to adjust monitor setup automatically. It only works for VGA input
- 8. Without entering OSD MENU, press ◀ / ► buttons to adjust the audio volume
- 9. Without entering OSD MENU, press HDMI, DVI & VGA buttons to select desired input source
- Press '4:3 / 16:9' button to change aspect ratio or zoom
   VGA input source only allows monitor to change the screen to 4:3 and 16:9 aspect ratio
   HDMI & DVI input sources allow monitor to change the screen to 4:3 and 16:9 aspect ratio, or make the zoom for monitor
- 11. Press the 'MUTE' button to on / off audio

# **CONTROL AND FUNCTION**

## **On Monitor, Button Control**



- 1. Source Select an input source
- Menu Enter the MENU, save the adjustment of submenu and exit the OSD
- Left & Right ◄ (VOL) ►
   Change the value on selected menu
- Up & Down ▲ ▼
   Switch a menu on OSD

- 5. Power Monitor power on / off
- LED Indicator Blue color: monitor on Red color : monitor off / power saving mode
- 7. IR Receiver

### **Monitor Button Function**

All picture, sound settings and setup can be adjusted in OSD (On Screen Display) menu. To adjust the OSD screen:

- 1. Press the **MENU** button to enter the **OSD MENU**
- 2. Press the ▲ / ▼ buttons to select the desired main-MENU. The selected main-MENU is highlighted
- 3. Press the MENU buttons to select the desired sub-MENU. The selected sub-MENU is highlighted
- 4. Press the  $\blacktriangle$  /  $\bigtriangledown$  button to select different item to adjust value
- 5. Press the MENU buttons to adjust value of item in sub-MENU. The selected sub-MENU is highlighted
- 6. Change the value you wish to adjust by using the ◀ / ► buttons
- 7. Press the SOURCE button to confirm the adjustment on sub-MENU
- 8. Press the SOURCE button to exit the sub-MENU and go back to the main-MENU
- 9. Press the SOURCE button to exit the OSD MENU




# **CONTROL AND FUNCTION**

## **Select Input Source - Monitor Button Function**

INPUT	
VGA DVI HDMI	I

Press 'SOURCE' button on monitor or 'HDMI / DVI / VGA' button on remote controller Press ▲ / ▼ button to change input source and then press 'MENU' button to select input source on monitor Press 'HDMI / DVI / VGA' button to select input source on remote controller

### Volume



Press ◀ / ► buttons to adjust volume on monitor

Press ◀ / ► buttons to adjust volume on remote controller

## Auto Detect Source / No Signal / Out of Range Message



No Signal Message : If you did not connect any input source, monitor will show 'No Signal' message and go into stand-by mode. Input Message : If you connect any input source, monitor will detect it automatically and identify it by the type of input source it is - HDMI, DVI or VGA.

Out of Range Message: If you connect a specific input source that is out of range on panel frequency (ref. page #17), you will see this message. In this case, please connect proper frequency input source.

# **CONTROL AND FUNCTION**

### Picture


Picture
Brightness Contrast
Gamma
1920x1080 @60.0Hz

#### ▲/▼ MOVE ◀/► SELECT(ADJUST) MENU RETURN

	FUNCTION	VALUE
BRIGHTNESS	Adjust the brightness	0~100
CONTRAST	Adjust the contrast	0~100
GAMMA	Adjust the Strength of RGB color	ON / OFF

### Position





Auto Adjustment Process

▲/▼ MOVE ◀/► SELECT(ADJUST) MENU RETURN

	VALUE	
PHASE <sup>1)</sup>	Adjust the vertical noise of screen image	0~100
CLOCK <sup>1)</sup>	Adjust the number of horizontal picture elements	0~100
H-Position <sup>1)</sup>	Adjust the horizontal position of picture	0~100
V-Position <sup>1)</sup>	Adjust the vertical position of picture	0~100
Auto Adjustment	Fit the image size automatically	
1) Only available in VGA mode		

Visit the ViewZ USA website at https://www.viewzusa.com



# **CONTROL AND FUNCTION**

### Color

Color
Color Temperature
Red
Green
Blue
1920x1080 @60.0Hz

#### ▲/▼ MOVE ◀/► SELECT(ADJUST) MENU RETURN

	FUNCTION	VALUE
COLOR TEMPERATURE	Adjust the color setting	See table below
RED <sup>1)</sup>	Adjust the intensity of RED color	0~100
GREEN <sup>1)</sup>	Adjust the intensity of GREEN color	0~100
BLUE <sup>1)</sup>	Adjust the intensity of BLUE color	0~100

1) Only available when select 'USER' mode on 'COLOR TEMPERATURE'

AVAILABLE COLOR TEMP.
5000K
6500K
7500K
8200K
9300K
11500K
sRGB
USER

# **CONTROL AND FUNCTION**

## OSD



▲/▼ MOVE ◀/► SELECT(ADJUST) MENU RETURN

	FUNCTION	VALUE
H-Position	Adjust the horizontal OSD position	0~100
V-Position	Adjust the vertical OSD position	0~100
Transparency	Set the OSD MENU transparency	$0 \sim 4^{1)}$
OSD Time Out	Set the OSD display time	0~60


1) 0 : No transparency of OSD Menu

4 : Max Transparency of OSD Menu



# **CONTROL AND FUNCTION**

### Setup



▲/▼ MOVE ◀/► SELECT(ADJUST) MENU RETURN

	FUNCTION	VALUE
LANGUAGE	Set the language of the OSD menu	English, Spanish, French, Italian
		German, Denmark, Poland
MUTE	Mute the sound	ON / OFF
INPUT	Change the input source	HDMI / DVI / VGA
DCR	Set the automatic adjustment for overall brightness	ON / OFF
DISPLAY SIZE	Adjust the video format	16:9 / 4:3 / ZOOM <sup>1)</sup>
RESET	Reset the monitor settings to the factory default	


1) HDMI / DVI supports 16:9 / 4:3 / ZOOM

VGA only supports 16:9 / 4:3

# **MOUNTING GUIDE**

## Wall Mounting (Optional)

VZ-CME monitors are suitable for VESA wall mount (not included in the delivery).



1. VZ-19CME, VZ-22CME, VZ-24CME : VESA WALL MOUNT 100mm x 100mm



### Attention!

VZ-CME : You must use 4 \* M4 x L8 screws to assemble this monitor and the wall mount bracket.

### 

WARNING !

If user uses screws longer than M4 x L8 mm, it may cause damage to the unit. Please use bolt of correct size and length as instructed.



### Mounting Safety !

At least two people are recommended to safely install the mount.

# **SPECIFICATION**

	Model No.	VZ-19CME	VZ-22CME	VZ-24CME
	Size & Type	19.5"	21.5"	24"
	Panel Type	19.5" LED Backlit Monitor	21.5" LED Backlit Monitor	24" LED Backlit Monitor
	Pixel Pitch	0.2265 (H) x 0.2265 (V) mm	0.24795 (H) x 0.24795 (V) mm	0.2715 (H) x 0.2715 (V) mm
	Brightness	200 cd/m <sup>2</sup>	220 cd/m <sup>2</sup>	300 cd/m <sup>2</sup>
	Contrast Ratio	3000 : 1(Typ.)	3000 : 1(Typ.)	1000 : 1(Тур.)
LCD	Viewing Angle	R/L:88°/88° U/D:88°/88°	R/L : 89°/ 89° U/D : 89°/ 89°	R/L : 85°/ 85° U/D : 80°/ 80°
	Display Color	16.7 Million Colors		
	Response Time	< 25 ms	< 30 ms	< 5 ms
	Active Display Area	434.88 (H) x 238.68 (V) mm	476.06 (H) x 267.78 (V) mm	521.28 (H) x 293.22 (V) mm
Max. Resolution 1920 (H) x 1080 (V)				
Case Type			Black Plastic	
Aspect Ratio			16 : 9 ( 4:3 Option )	
Color Temperature		5000K / 6500K	. / 7500К / 8200К / 9300К / 11500К	/ sRGB / USER
Speaker			2 x 2W	
Operating Temperature			14°F ~ 122°F / -10°C ~ 50°C	
Operating Humidity			20 ~ 70% RH	
	Weight	Net : 7.05 lb / 3.2 kg	Net : 8.81 lb / 4.0 kg	Net : 9.92 lb / 4.5 kg
	weight	Gross : 8.37 lb / 3.8 kg	Gross : 10.14 lb / 4.6 kg	Gross : 10.36 lb / 4.7 kg
	INTERFACE	HDM	II (High Definition Multimedia Inter	face)
	INTERFACE	DVI (Digital Vi	deo Interface), VGA (RGB-PC), PC S	tereo In / Out
Safety	& EMC Certification	n CE / FCC / ROHS /WEEE		
Electrical Ratings 12V DC, 3A (AC 100-240V, 50/60Hz)		)		
Ρον	ver Consumption	≤ 24 W	≤ 25 W	≤ 28 W
Accessories HDMI cable, Powe		er Supply & Cable, User's Manual, F	Remote controller	

ViewZ

# **TROUBLESHOOTING GUIDE**

- Check the following before calling for service.

- If the same problems continue after checking, contact the reseller you purchased the monitor from.

At start	We recommend that you test with different input sources when you have trouble with the current input source. If symptom persists, follow the instructions below. After following the instructions below, please contact us at 1-888-99-VIEWZ.		
No image or Noise on the screen	<ul> <li>Make sure the cable is correctly plugged into the outlet</li> <li>Make sure the power cable is correctly plugged into the monitor</li> <li>Make sure the cable is correctly connected between monitor &amp; source</li> <li>Check brightness and see if brightness is set to 'Ø'</li> <li>Check video source</li> </ul>		
Incorrect display or Half display- Check your video source - Reset video source : connection, cable replacement, setting & more			
Flickering and shadow image- Check your input source setting for resolution and phase (Hz)The audio function is not working- Check the volume and make sure MUTE is not on - Check HDMI / Audio port cable connection			
		LED is flickering or no image	<ul> <li>Check the interface cable connection and make sure it's plugged in correctly</li> <li>Check the input source</li> </ul>



# **TERMS OF WARRANTY / RMA**

- The warranty period for this monitor is 3 years. The warranty will be voided for the scenarios listed below.

- You can also download the manual and information of VIEWZ web site: VIEWZUSA.COM

Cases of Non-Warranty Coverage	When power feed to the monitor exceeds capacity and causes damage
	Accident, Abuse, Misuse, Neglect, Fire, Water/liquids, Lightning or any act of nature
	Damaged by dropping, throwing and hitting the monitor
	Failure caused by users attempt to modify the product
	Failure by limited life of parts such as LED Lamps and any other consumables
	Damaged by using third party power cable, unstable power input and electric shock

- \* Above information can be changed without notification please check our website or contact ViewZ representative for latest RMA service policy.
- \* When shipping the monitor for RMA, make sure to pack safely to ensure the monitor is not damaged during shipping.

# WARRANTY

### ViewZ USA LIMITED 3 YEAR WARRANTY

#### What and Who is Covered by this Limited Warranty and for How Long

ViewZ USA warrants this product to be free from defects in material and workmanship for 3 years to the original owner of this product. The limited warranty is valid only for the original purchaser of the product.

#### What ViewZ USA Will Do

At the sole discretion of ViewZ USA, ViewZ USA will repair or replace any product or product part that is defective. If ViewZ USA chooses to replace a defective product or part, a replacement product or part will be shipped to you at no charge, but you must pay any labor costs.

#### What is Not Covered; Limitations

ViewZ USA disclaims any liability for damage to mounts, adapters, displays, projectors, other property, or personal injury resulting, in whole or in part, from improper installation, modification, use or misuse of its products.

ViewZ USA disclaims all other warranties, express or implied, including warranties of merchantability and fitness for a particular purpose. ViewZ USA is not responsible for incidental or consequential damages, including but not limited to, inability to use its products or labor costs for removing and replacing defective products or parts. Some states do not allow the exclusion or limitation of incidental or consequential damage, so the above limitation or exclusion many not apply to you.

#### What Customers Must Do for Limited Warranty Service

If you discover a problem that you think may be covered by the warranty you MUST REPORT it in writing to the address below within thirty (30) days. Proof of purchase (an original sales receipt) from the original consumer purchaser must accompany all warranty claims. Warranty claims must also include a description of the problem, the purchaser's name, address, and telephone number. General inquiries can be addressed to ViewZ USA Customer Service at 1-888-998-4399. Warranty claims will not be accepted over the phone or by fax.

ViewZ USA Attn: Warranty Claim 177 W. Orangethorpe Ave. Placentia, CA 92870

#### **How State Law Applies**

This warranty gives you specific legal rights, and you may also have other rights which vary from state to state.

#### Disclaimer

ViewZ USA intends to make this manual accurate and complete. However, ViewZ USA makes no claim that the information contained herein covers all details, conditions or variations, nor does it provide for every possible contingency in connection with the installation or use of this monitor. The information contained in this document is subject to change without notice or obligation of any kind. ViewZ USA makes no representation of warranty, expressed or implied, regarding the information contained herein. ViewZ USA assumes no responsibility for accuracy, completeness or sufficiency of the information contained in this document.

#### **Contact Us**

#### NORTH AMERICA

177 W. Orangethorpe Ave. Placentia, CA 92870 USA and Canada Phone: 1-888-998-4399 Fax: 1-714-996-1138 Other Locations Phone: (001) 888-998-4399 Fax: (001) 714-996-1138

© ViewZ USA